



# **Brochure Sheet**

# **Alignment Coupling**

The **Dense Flow Alignment Coupling** is used to connect pipe or tubing, and its design helps to minimize pipeline abrasion cause by misalignment.





Coupling collars are welded on the two ends of pipe that are being joined, one end creates a male connection and the other a female connection. Two 150# B.C. slip on flanges compress a gasket between the two coupling collars to insure an air tight seal up to 125psi.

#### **Features**

- Coupling Collars
- Quad Ring Gasket
- Slip on Flanges (150# B.C.)
- Nuts & Bolts

## **Benefits**

- Proper Pipe Alignment
- Less Abrasion From Misalignment
- Less System Downtime
- Lower Maintenance Cost

## **Applications**

- Pneumatic Conveying Pipelines
- Dense Phase
- Dilute Phase
- Truck Unload

